

Подходит к моделям:

ACER

Aspire S7-191

Aspire S7-191-53314g12ass/i5-3317U

Aspire S7-191-53314g12ass

Aspire S7-191-6400/i5-3317U

Aspire S7-191-6640

Aspire S7-191-6647

Aspire S7-191-6647/i5-3317U

Aspire S7-191-6647/i5-3337U

Aspire S7-191-6859

Aspire S7-191-6859/i5-3317U

Aspire S7-191-73514g25ass/i7-3517U

Aspire S7-191-73514g25ass

Aspire S7-391

Aspire S7-391-53314G

Aspire S7-391-53314G12aws

Aspire S7-391-53314G12aws/i5-3317U

Aspire S7-391-53334G12aws

Aspire S7-391-53334G12aws/i5-3337U

Aspire S7-391-6413

Aspire S7-391-6413/i5-3337U

Aspire S7-391-6468

Aspire S7-391-6468/i5-3337U

Aspire S7-391-6478

Aspire S7-391-6478/i5-3317U

Aspire S7-391-6662

Aspire S7-391-6677

Aspire S7-391-6810

Aspire S7-391-6810/i5-3317U

Aspire S7-391-6822

Aspire S7-391-6822/i5-3317U

Aspire S7-391-6878

Aspire S7-391-73514G

Aspire S7-391-73514G12aws/i7-3517U

Aspire S7-391-73514G25aws

Aspire S7-391-9411

Aspire S7-391-9413

Aspire S7-391-9427

Aspire S7-391-9427/i7-3517U

Aspire S7-391-9492

Aspire S7-391-9492/i7-3537U

Aspire S7-391-9604

Aspire S7-391-9839/i7-3517U

Aspire S7-391-9886

Aspire S7-391-9886/i7-3517U

Aspire S7-391