

Подходит к моделям:

LifeBook M Series

LifeBook M1010

LifeBook MH Series

LifeBook MH380

LifeBook UH Series

LifeBook UH900

STYLISTIC Series

Q550

Q550LB

MSI

MS Series

MS-1351

MS-1352

MS-1353

MS-1354

MS-1355

MS-1356

MS-1357

MS-1358

MS-1359

MS-135A

MS-135B

MS-135C

MS-135D

MS-135E

MS-135F

MS-135G

MS-135H

MS-135I

MS-135J

MS-135K

MS-135L

MS-135M

MS-135N

MS-135O

MS-135P

MS-135Q

MS-135R

MS-135S

MS-135T

MS-135U

MS-135V

MS-135W

MS-135X

MS-135Y

MS-135Z

R Series

R3700

X Series

X370

IBM/LENOVO M30 70 ,

IBM/LENOVO S10 ,

IBM/LENOVO S10 2 ,

IBM/LENOVO S10 2 2957 I2u ,

IBM/LENOVO S10 2 2957J9J ,

IBM/LENOVO S10 2 2957JLJ ,

IBM/LENOVO S10 2 2957JPJ ,
IBM/LENOVO S10 2 2957JQJ ,
IBM/LENOVO S10 2 2957JUJ ,
IBM/LENOVO S10 2 2957JXJ ,
IBM/LENOVO S10 2 2957KJJ ,
IBM/LENOVO S10 2 2957KKJ ,
IBM/LENOVO S10 2 2957KLJ ,
IBM/LENOVO S10 2C ,
IBM/LENOVO S10 3 ,
IBM/LENOVO S10 3 0647 2bu ,
IBM/LENOVO S10 3 064793J ,
IBM/LENOVO S10 3 064796J ,
IBM/LENOVO S10 3 064797J ,
IBM/LENOVO S10 3c ,
IBM/LENOVO S10 3s ,
IBM/LENOVO S10 3t ,
IBM/LENOVO S10 3T 065149J ,
IBM/LENOVO S10 3T 06514AJ ,
IBM/LENOVO S10 T3 ,
IBM/LENOVO S100 ,
IBM/LENOVO S10e ,
IBM/LENOVO S10E 4068 4SG ,
IBM/LENOVO S10G ,
IBM/LENOVO S10W ,
IBM/LENOVO S12 ,
IBM/LENOVO S12 2959H8J ,
IBM/LENOVO S12 2959H9J ,
IBM/LENOVO S12 2959HHJ ,
IBM/LENOVO S12 2959HJJ ,
IBM/LENOVO S205 ,
IBM/LENOVO S205S ,
IBM/LENOVO S435 ,
IBM/LENOVO S9 ,
IBM/LENOVO S9e ,
IBM/LENOVO U160 ,