

Подходит к моделям:

Gateway Series: 200, 200ARC;

Samsung Series: N, N110-12PBK, Series: N110, N110-12PBK, N110-anyNet N270 BBT, Series: N120, N120-12GBK, N120-12GW, N120-anyNet N270 BBT, N120-anyNet N270 BN59, N120-anyNet N270 WBT, N120-anyNet N270 WN59, Series: N130, N130-13B, N130-13P, N130-anyNet N270 B3N, N130-anyNet N270 BN7, N130-anyNet N270 WN, N130-anyNet N270 WN7, N130-anyNet N270BN, N130-anyNet N280BN, Series: N140, N140-14B, N140-14R, N140-anyNet N270 BNB21, N140-anyNet N270 WNB21, Series: N150, N150-Elijah, N150-Eom 3G, Series: N220, N220-Maroh, N220-Marvel, N220-Mito, Series: N310, N310, N310-13GB, N310-13GO, N310-anyNet N270 BBT, N310-anyNet N270 MBT, Series: N510, N150-Elijah, N510-BN7BT, N510-Mika, N510-Mika 3G, N510-Mila, N510-Mino, N510-anyNet N270 WBT21, Series: NB30, NB30, NB30-Pro Palm, NB30-Pro Palm Touch, Series: NC, NC10, NC20, Series: NC10, NC10-11GP, NC10-12PWBK, NC10-13GB, NC10-13P, NC10-14GB, NC10-14GBK, NC10-14GW, NC10-anyNet N270 A, NC10-anyNet N270 B, NC10-anyNet N270 BBT, NC10-anyNet N270 BH, NC10-anyNet N270 WBT, NC10-anyNet N270 WH, NC10-anyNet N270W, Series: NC20, NC20-21GBK, NC20-anyNet U2250 WBT, Series: P, P28, P30, P460-42P, P460-44G, P460-44P, P560-52P, P560-54G, P560-54P, Series: Q, NP-Q1, NP-Q1EX, NP-Q35, NP-Q70, Q1EX-71G, Q1U-ELXP, Q1U-SSDXP, Q1U-XP, Q1UP-V, Q1UP-XP, Q30, Q310-34G, Q310-34P, Q320-32P, Series: R, R50, R522-52S, R610-62G, R610-64G, R620-63G, Series: X, X1, X10, X20, X360-34G, X360-34P, X460-41P, X460-41S, X460-42PW, X460-44G, X460-44P, Series: X120, X120-Aura SU7300 Akio, X120-Aura SU7300 Avion, Series: X420, X420-Aura SU2700 Aven, X420-Aura SU3500 Anno, X420-Aura SU4100 Kami, X420-Aura SU4100 Logan, Series: X520, X520-Aura SU2700 Addi, X520-Aura SU3500 Alon, X520-Aura SU4100 Akiva, Voltage :18 - 20, VRate :85 - 155Wh, Series: A, A10, A10 DXT, A10 XTC, Series: Aquila, Aquila, Aquila C, Series: Corona, Corona, Series: GT, GT6000, GT6330, GT6330XT, GT6360, GT6360XT, GT6400, GT6400XV, GT7000, GT7700, GT8000, GT8100, GT8600, GT8600XT, GT8650, GT8650XT, GT8700, GT8700XT, GT8750, GT8750XT, GT8750XV, GT8800, GT8800XT, GT8800XV, GT8850, GT8850XT, GT8850XTD, GT8900, GT8900DXV, GT8900XTR, GT8910, GT8910KXV, GT9000, GT9000 PRO, Series: M, M40, M40 plus, M50, Series: N, N110-12PBK, Series: NC, NC10, NC20, Series: P, P28, P30, P35, P40, P460-44G, P460-44P, P50, P560 AA02, P560 AA03, P560 AA04, Series: Q, NP-Q1, NP-Q1EX, NP-Q1U, NP-Q30, NP-Q30 Plus, NP-Q35, NP-Q70, Q1, Q1 Ultra, Q1EX-71G, Q1U, Q1U-ELXP, Q1U-SSDXP, Q1U-V, Q1U-XP, Q1UP-V, Q1UP-XP, Q210 AS01, Q210 AS05, Q210 FS01, Q30, Q30 plus, Q310-34G, Q310-34P, Q35, Series: R, NP-R50, R20, R20-Aura T2350 Declan, R20-Aura T7200 Deva, R50, R505 FS02, R505 FS03, R505 FS04, R510 AS01, R510 AS04, R510 AS05, R510 AS07, R510 AS08, R510 FA01, R510 FA02, R510 FA06, R510 FA07, R510 FA09, R510 FA0E, R510 FS01, R510 FS08, R510 FS09, R510 FS0A, R510 XS01, R55, R610 AS02, R610 AS03, R610 AS04, R610 AS05, R610 AS06, R610 AS07, R610 AS08, R610 FS02, R710 AS01, R710 AS02, R710 AS08, R710 AS0A, R710 AS0B, R710 AS0D, R710 FA01, R710 FS01, Series: SN, SN6000, Series: Sens, Sens 690, Sens 820, Sens 830, Sens 900, Sens 950, Sens Pro 680, Sens Pro 850, Sens V10, Series: T, T10, Series: V, V20, Series: VM, VM6000, VM6300, VM6300cT, VM7000, VM7550, VM7550cT, VM7600, VM7600cT, VM7650, VM7650cT, VM7650cXTD, VM7700, VM7700XTD, VM8000, VM8080cXT, VM8090cT, VM8090cXTD, VM8095cX, VM8100, VM8100XTD, VM8100cX, VM8100cXTD, VM8110XTC, VM8110cXTD, Series: X, NP-X20, NP-X60, NT-X11, X05, X05 Plus, X1, X1-1200 Bliss, X10, X10 plus, X11, X11-Pro T2600 Baviall, X11-Pro T5500 Bugomi, X11-Pro T7400 Bennett, X11-T2300 Carl, X11-T2300 Culesa, X11-T5500 CeSeba, X11c-T5600 Calest, X11c-T7200 Carlin, X15, X15 plus, X20, X22, X30, X360 AA02, X360 AA03, X360-34G, X360-34P, X460 AS03, X460 FA01, X460-44G, X460-44P, X50, X50 WVM 2000, X60, X60-Pro T7200 Benito, X60-Pro T7400 Boxxer, Series: 6000, 6000, Series: 8000, 8000GS, 8000SN, 8000VN;

ARM Series: ArmNote, ArmNote CY23, ArmNote CY25, ArmNote CY27

