


Tefal®





CLASSIC

PP15xx

Instruction manual – Notice d'utilisation – Gebruiksaanwijzing – Bedienungsanleitung –
Manuale di istruzioni – Manual de instrucciones – Manual de instruções – Εγχειρίδιο οδηγιών –
Kullanma kılavuzu – Instrukcja obsługi – Uživatelská příručka – Használati útmutató – Návod na použitie –
Manual de instrucțiuni – Uputstvo za upotrebu – Upute za uporabu – Ръководство с инструкции –
Руководство по експлуатации – Príročník z navodili – Посібник з експлуатації - Kasutusjuhend -
Instrukcijas - Instrukcijų vadovas





www.tefal.com

1820004754



Tefal
Classic

UTILISATION / USE / ИНСТРУКЦИЯ







MINI 10 kg / 2 st / 22 lb
МИНИМАЛЬНЫЙ ВЕС







MAXI 160 kg / 25 st / 352 lb
МАКСИМАЛЬНЫЙ ВЕС

2 UNITÉS / UNITS / БЛОК (kg > lb > st.lb)







kg > lb > st.lb

3 INSTRUCTIONS / ИНСТРУКЦИЯ



4 PILE / BATTERY / БАТАРЕИ



5 INTERDICTIONS / FORBIDDEN / ЗАПРЕЩЕНО

