

Аккумулятор можно использовать вместо оригинального:

KODAK

KLIC-5001

SANYO

DB-L50 DB-L50AU

Подходит к моделям:

SANYO

Xacti DMX-FH11 Xacti DMX-FH11K Xacti DMX-HD1000

Xacti DMX-HD1000K Xacti DMX-HD1000S Xacti DMX-HD1010

Xacti DMX-HD1010K Xacti DMX-HD1010S Xacti DMX-HD2000

Xacti DMX-HD2000K Xacti DMX-HD2000N Xacti DMX-TH1

Xacti DMX-TH1S Xacti DMX-WH1 Xacti DMX-WH1E

Xacti DMX-WH1EL Xacti DMX-WH1W Xacti DMX-WH1Y

Xacti VPC-FH1ABK Xacti VPC-FH1BK Xacti VPC-FH1EBK

Xacti VPC-HD1000 Xacti VPC-HD1010 Xacti VPC-HD1010BK

Xacti VPC-HD2000 Xacti VPC-HD2000ABK Xacti VPC-HD2000EBK

Xacti VPC-TH1 Xacti VPC-TH1BL Xacti VPC-TH1EX-B

Xacti VPC-TH1EXBL-B Xacti VPC-TH1EXR-B Xacti VPC-TH1R

Xacti VPC-TH2 Xacti VPC-WH1 Xacti VPC-WH1BL

Xacti VPC-WH1EXBL-B Xacti VPC-WH1EXW-B Xacti VPC-WH1EXYL-B

Xacti VPC-WH1YL

KODAK

EasyShare DX6490 EasyShare DX7440 EasyShare DX7440 Zoom

EasyShare DX7590 EasyShare DX7590 Zoom EasyShare DX7630

EasyShare P712 EasyShare P850 EasyShare P880

EasyShare Z730 EasyShare Z730 Zoom EasyShare Z7590

EasyShare Z7590 Zoom EasyShare Z760 EasyShare Z760 Zoom