

Маша и Медведь™

Маша и Медведь™

Маша и Медведь™

GPS WATCH
for kids



© Анимакорд ЛТД, 2008-2017
www.mashabear.ru



Владелец товарного знака является ООО «Маша и Медведь»

© Montex Swiss AG

AGU® is the registered trademark
by Montex Swiss AG, Tramstrasse 16,
Berneck, Switzerland


Licensed territory:
RU, UKR, BLR, KAZ, GEO,
ARM, LTU, LVA, EST.

1 




- 1 micro USB slot
- 2 call answer button / SOS button / back button
- 3 watch take-off sensor
- 4 micro SIM card slot

2 



- 5 SIM card slot is empty
- 6 signal level
- 7 GPS signal availability
- 8 sound on / vibration only mode
- 9 watch take-off indicator
- 10 alarm clock
- 11 date
- 12 number of likes
- 13 battery charge
- 14 time
- 15 speed dial button 1 / in the phone book - up in the list
- 16 on/off button / end a call
- 17 press once - enter the phone book / hold the button - speed dial button 2 / click in the phone book - down in the list / hold in the phone book - call the selected contact
- 18 day of the week
- 19 USB cable
- 20 phone book

3 



before installing the micro SIM card turn off the PIN code lock function



3 find AGU app




or scan this QR code




4 start the application



7 fill in the baby profile



5 register or login with a social network



8 connect the device



6 select the device



9 follow the instructions in the app

